



RolloPort S2

Accessories



RP-S2-MHS-RF23
2 channel micro manual transmitter
433 MHz



RP-S2-HS-RF11
2-channel manual transmitter 433 MHz
incl. wall bracket



RP-S2-CSG-AF26
Radio code switch 433 MHz



4595
Key sensor with cylinder, flush-mounted,
for opening the garage door manually from
outside, lockable on both sides



4596
Key sensor with cylinder, surface-mount-
ed, for opening the garage door manually
from outside, lockable on both sides



4593
Key sensor without cylinder, flush-
mounted (for profile cylinders with lockable
setting 0° above, lockable on both sides)




4594
Key sensor without cylinder, surface-
mounted (for profile cylinders with lockable
setting 0° above, lockable on both sides)



4590
Internal sensor for opening the garage door



4603
Standard code switch, code lock with number entry, consisting of a keypad and a control unit



RP-S2-543-01
External release for swing doors, for manual opening from outside



RP-S2-543-02
External release for sectional doors, for manual opening from outside



4560-03
Sectional door bracket



4591
Perforated bracket, length 770 mm
